

Installation Instructions

Hands-Free Foot Door Opener



ltem No.	Description
DRFTPULL-V	Hands-Free Foot Door Opener

INSTALLATION

Kit Contents

Part	Quantity
DRFTPULL-V (foot door opener bracket)	1
Sheet Metal Screw, 1-1/4"	3
Decal, Hands-Free Foot Door Opener	1

Tools You Will Need

- Drill and 5/32" drill bit
- Phillips head screwdriver
- 1. Place the bracket upside down at the bottom corner of the swinging edge of the door with hole array flange facing upward and pushed flush against the door.
- 2. Space the bracket inwards from the swing edge of the door approximately 3/4".



- Drill through the center hole with a 5/32" drill bit to a depth of 1 ¼" and then insert and tighten one of the provided sheet metal screws.
- 4. Make sure the bracket is level, then drill out the other two holes using the bracket as a template



- 5. Remove the installation screw and flip the bracket over so the grip tape surface faces up.
- Install the 3 sheet metal screws in the predrilled holes to secure the bracket in place. Tighten screws until the bracket is firmly secure.



7. Place the toe or foot on the bracket and pull towards you to open door without the use of your hands.

Note: the ADA provides recommendations on door force pull settings and basic instructions on how to adjust the most common types of doors to open more easily. This information from the ADA can be found at https://adata.org/factsheet/adjusting-doors-access

 Install the provided decal in an easily visible location. Clean and dry the surface where the decal is going before applying it to ensure a strong bond.





www.vollrathfoodservice.com

The Vollrath Company, L.L.C. 1236 North 18th Street Sheboygan, WI 53081-3201 U.S.A. Main Tel: 800.624.2051 or 920.457.4851 Main Fax: 800.752.5620 or 920.459.6573 Customer Service: 800.628.0830 Canada Customer Service: 800.695.8560

Technical Services

techservicereps@vollrathco.com Induction Products: 800.825.6036 Countertop Warming Products: 800.354.1970 Toasters: 800-309-2250 All Other Products: 800.628.0832