


15 Bird Chicken Rotisserie Oven

Item Number(s): 40841



Callout	Part No.	Description	Callout	Part No.	Description
1.	N/A	Top cover assembly	21.	XCOA1003	Timer
2.	N/A	Top cover insert	22.	XCGA0034	Geared motor
3.	N/A	Fan motor cover	23.	N/A	Side cover panel right
4.	N/A	Left carousel support	24.	XFTA0002	Terminal block
5.	N/A	Left cover side panel	25.	XSAA8030	Power cord, 220V, NEMA 6-30p
6.	N/A	Left cover insert	26.	XCOA5012	Cable restraint
7.	XCGA0031	Element, 220V, 2500Watts	27.	XCOA5024	Contactor
8.	XCGA0016	Glass door magnet	28.	N/A	Right cover insert
9.	XCGA0010	Door hinge	29.	N/A	Right carousel support
10.	N/A	Door handle	30.	XCOA1041	Light bulb, 220V
11.	N/A	Door handler bracket	31.	XCOA1015	Light holder
12.	XCGA0033	Front glass door	32.	XCOA1021	Fan and motor, 220V, left hand thread
13.	XCGA0006	Drip tray	33.	XCGA0035	Rear glass
14.	N/A	Base	34.	XCGA0005	Carousel flange left
15.	XCOA1008	Timer knob, Vollrath blue	35.	XCGA0032	Main shaft
16.	XCOA1009	Control knob (0-550°F) Vollrath blue	36.	XCGA0030	Chicken griller basket
17.	XCOA1009	Adjustable foot	37.	XCGA0012	Carousel end plate
18.	XCOA1002	Thermostat	38.	XCGA0003	Basket retaining pin
19.	XWMA1004	Rocker switch	39.	N/A	Carousel bearing right
20.	XAA0002	Pilot light, 220V (red)			