




4 WELL HOT & COLD
120/208-240V
WIRING DIAGRAM
CONTROL BOX

IMPORTANT
—
PLEASE OBSERVE
VIEWER
ORIENTATION NOTE
IN EACH BOX






4 WELL HOT & COLD
120/208-240V
WIRING DIAGRAM

WIRE CHANNEL BOX
WELLS
1 & 2

IMPORTANT
—
PLEASE OBSERVE
VIEWER
ORIENTATION NOTE
IN EACH BOX

12-WIRE
CONDUIT



WIRE CHANNEL BOX, WELLS 1 & 2 (as viewed from operator side)

