



Outperform every day.™

# Technical Field Information

## Stoelting® Granita Frozen Beverage Dispenser Cotter Pin Replacement

Item Number(s): CBE117-37, CBE127-37, CBE167-37

### TOOLS REQUIRED:


- Phillips head screwdriver
- Needle nose pliers
- Wire snipper

### LOCATE THE REPLACEMENT PARTS

1. Turn off and unplug the machine.



2. Remove the power-side panel. Locate the bag of spare parts.



3. Identify the type of cotter pin in the bag.

**S-Curve Pin**




**Straight Pin**



### S-CURVE PIN


1. Replace the pin.



2. Replace the panel.
3. Plug in and turn on the machine.

### STRAIGHT PIN

1. Insert the new pin.




2. Use pliers to separate and bend each side of the pin so each is flat against the shaft. Use one hand to hold the shaft to keep it from rotating while using the hand to separate the pin.



3. Trim the ends.



4. Rotate the shaft to verify the trimmed pin does not interfere with other components.



5. Replace the panel.

6. Plug in and turn on the machine.



Outperform every day.™

[www.vollrath.com](http://www.vollrath.com)

**The Vollrath Company, L.L.C.**

1236 North 18th Street  
Sheboygan, WI 53081-3201 U.S.A.  
Main Tel: 800.624.2051 or 920.457.4851  
Main Fax: 800.752.5620 or 920.459.6573  
Customer Service: 800.628.0830  
Canada Customer Service: 800.695.8560

Technical Services

[techservicereps@vollrathco.com](mailto:techservicereps@vollrathco.com)  
Induction Products: 800.825.6036  
Countertop Warming Products: 800.354.1970  
All Other Products: 800.628.0832