

Stoelting® Granita Frozen Beverage Dispenser Fuse Replacement

Item Number(s): CBE117-37, CBE127-37, CBE167-37

TOOLS REQUIRED


- Phillips head screwdriver

LOCATE THE SPARE PARTS

1. Turn off and unplug the machine. Turn off and unplug the machine.



2. Remove the power side panel. Locate the bag of spare parts.



3. Locate the fuses in the bag. Fuses are color coded and amp rating is stamped on the end caps.

5 Amp Fuse
(blue and green stripes)




315 mAmp Fuse
(shades of red stripes)



REPLACE THE FUSE(S)

5 Amp Fuse Replacement

1. Locate the fuse holder.




2. Replace the fuse.
3. Replace the side panel cover.

315 mAmp Fuse Replacement

One Bowl Machine


1. Locate the fuse holder.



2. Replace the fuse(s).
3. Replace the back panel.

Two and Three Bowl Machines

1. Remove the back panel. Locate the fuses. Three bowl machines have three fuses.



2. Replace the fuse(s).
3. Replace the side and back panels